MERCURY OUTBOARD REMOTE THROTTLE INSTALLATION Latest Edition

Comprehensive Guide to Mercury Outboard Remote Throttle Installation

Mercury outboard remote throttle installation is a critical process that enhances your boating experience by allowing precise control over your boat's speed and engine performance from a distance. Whether you're upgrading your existing setup or installing a remote throttle system for the first time, understanding each step ensures safety, efficiency, and optimal engine operation. This guide provides a detailed overview of the installation process, tools required, troubleshooting tips, and maintenance advice to help you achieve a professional-quality setup.

Understanding Mercury Outboard Remote Throttle Systems

What Is a Remote Throttle System?

A remote throttle system allows boat operators to control engine speed and gear shifting from a location separate from the engine itself, typically at the helm. This setup provides better ergonomics, improved safety, and enhanced control during navigation.

Components of a Mercury Outboard Remote Throttle System

- Throttle Control Box: The main interface for throttle and shift controls.
- Cables: Mechanical or electronic cables connecting the control box to the engine.
- Control Cable Brackets and Mounts: Hardware used to secure and route cables.
- Electrical Wiring: For electronic throttle systems, wiring connects sensors and control modules.
- Mounting Hardware: Bolts, screws, and brackets for installation.

Prerequisites and Preparations for Installation

Tools and Materials Needed

- Screwdrivers (Phillips and flat-head)
- Wrenches and socket set
- Wire strippers and crimpers (for electronic systems)

- Drill with appropriate bits
- Mounting brackets and hardware (supplied with kit)
- Marine-grade sealant (if needed)
- Replacement cables (if existing cables are damaged)
- User manual specific to your Mercury outboard model

Safety Precautions

- Disconnect the boat's battery before starting electrical wiring.
- Ensure the engine is turned off and cooled down.
- Use marine-grade electrical components to prevent corrosion.
- Follow manufacturer guidelines carefully.

Step-by-Step Mercury Outboard Remote Throttle Installation

1. Planning the Installation Layout

Before beginning, plan the placement of the control box at the helm and the routing of cables to the engine. Consider:

- Ease of access for operation
- Clear cable paths avoiding sharp bends
- Protection from water, heat, and moving parts
- Adequate length of cables for routing

2. Removing Existing Controls (if applicable)

- Disconnect and remove any existing throttle or shift controls.
- Clean mounting areas to prepare for new hardware.

3. Mounting the Throttle Control Box

- Position the control box at the helm, ensuring comfortable reach.
- Use the mounting brackets provided.
- Drill holes if necessary, applying marine sealant to prevent water ingress.
- Secure the control box firmly using appropriate hardware.

4. Connecting the Cables

Depending on the type of system, follow the specific steps:

For Mechanical Cables:

- Attach the throttle and shift cables to the control box, following the manufacturer's instructions.
- Route the cables through cable guides, clamps, or conduits to avoid chafing.
- Connect the other end of the cables to the engine's throttle and shift linkages.
- Adjust cable tension as per the manual to ensure smooth operation.

For Electronic Systems:

- Connect wiring harnesses from the control box to the engine?s electronic control module (ECM).
- Use waterproof connectors and ensure wiring is secure.
- Route wires along protected paths, avoiding hot or moving parts.
- Use heat-shrink tubing or marine-grade electrical tape for sealing connections.

5. Mounting and Connecting to the Engine

- Attach cables to the engine?s throttle and shift linkages or electronic inputs.
- Ensure proper alignment and secure all connections.
- Use cable clamps or brackets to prevent movement.

6. Testing the System

- Reconnect the boat's battery.
- Turn on the engine and test throttle and shift controls at the helm.
- Verify smooth operation, correct shifting, and acceleration.
- Adjust cable tension or electronic settings as needed.

Final Checks and Troubleshooting

Common Installation Issues

- Sticking or delayed throttle response

- Difficulty shifting gears
- Electrical connection problems
- Loose mounting or cables

Troubleshooting Tips

- Ensure cables are properly adjusted and not kinked.
- Check all electrical connections for corrosion or loose contacts.
- Verify that the control box is mounted securely.
- Consult the user manual for specific calibration procedures.

Maintenance and Upkeep of Mercury Remote Throttle Systems

Regular Inspection

- Check cables and wiring for signs of wear or corrosion.
- Ensure mounting hardware remains tight.
- Test throttle and shift response periodically.

Cleaning and Lubrication

- Clean control components with freshwater to remove salt and dirt.
- Lubricate mechanical cables with marine-grade lubricant to maintain smooth operation.

Replacing Components

- Use genuine Mercury parts for replacements.
- Follow manufacturer instructions for replacing cables or control units.

Benefits of Proper Mercury Outboard Remote Throttle Installation

- Improved safety by allowing better control from the helm.
- Increased comfort and convenience during operation.
- Enhanced engine responsiveness and performance.
- Reduced risk of cable or wiring failure through proper routing and maintenance.

Conclusion

A well-executed **Mercury outboard remote throttle installation** is essential for optimal boat operation, safety, and enjoyment. By carefully planning the layout, following step-by-step installation procedures, and performing regular maintenance, boat owners can ensure their remote throttle system functions reliably for years to come. Always refer to the specific manual for your Mercury outboard model and consider professional installation if unsure about any step. Proper installation not only maximizes performance but also enhances your overall boating safety and experience.

Mercury Outboard Remote Throttle Installation: An Expert Guide

When it comes to enhancing your boating experience, the importance of a reliable, responsive throttle system cannot be overstated. For Mercury outboard owners, upgrading or installing a remote throttle can significantly improve control, safety, and convenience. This detailed guide dives into the intricacies of Mercury outboard remote throttle installation, offering expert insights, step-by-step procedures, and essential tips to ensure a successful setup.

Understanding the Mercury Outboard Remote Throttle System

Before diving into installation specifics, it?s crucial to grasp what a Mercury remote throttle system entails and why it?s a valuable upgrade.

What Is a Remote Throttle System?

A remote throttle system allows the boat operator to control engine speed and gear shifting from a location separate from the engine itself. This setup is especially useful for larger boats, dual-console configurations, or situations where the operator prefers to stay at the helm while controlling engine functions.

Key Components:

- Throttle and Shift Control Box: The physical interface located at the helm.
- Control Cables: Connect the control box to the engine, transmitting throttle and shift commands.
- Control Cable Brackets and Mounts: Secure the cables and control box.
- Electrical Wiring: Provides power and signal connections.
- Mounting Hardware: Screws, clamps, and brackets needed for installation.

Benefits of Upgrading to a Remote Throttle

- Enhanced Control: Precise throttle and shift adjustments.
- Improved Safety: Keeps the operator at the helm, reducing distractions.
- Convenience: Easier engine management during docking, fishing, or maneuvering.
- Aesthetic & Ergonomics: Cleaner cockpit layout with dedicated controls.

Preparing for Installation

Proper preparation is vital to a seamless installation process.

Assessing Your Boat and Engine Compatibility

- Model Compatibility: Not all Mercury engines support remote throttle systems. Consult your engine?s manual or Mercury?s product catalog.
- Control Box Compatibility: Ensure the control box matches your engine?s horsepower and model year.
- Cable Lengths: Measure the distance from the intended control location to the engine to select appropriate cable lengths.

Gathering Necessary Tools and Materials

- Tools:
- Screwdrivers (Phillips and flat-head)
- Wrenches and socket set
- Drill with bits
- Pliers
- Wire strippers
- Cable tension gauge (optional)
- Materials:
- Mercury remote throttle control kit
- Control cables
- Mounting brackets and hardware
- Electrical wiring harness
- Cable clamps and fasteners
- Sealant or waterproof connectors (if required)

Safety and Precautions

- Disconnect the boat?s battery before starting to prevent electrical accidents.

- Follow the manufacturer?s instructions meticulously.
- Work in a well-lit, dry environment.
- Keep track of all screws, nuts, and small components.

Step-by-Step Installation Process

This section offers a detailed walkthrough, divided into logical phases for clarity.

1. Mounting the Control Box

Placement Considerations:

- Position the control box within easy reach at the helm.
- Ensure it?s mounted on a sturdy, vibration-resistant surface.
- Avoid areas exposed to excessive moisture or direct sunlight.

Installation Steps:

- Mark the mounting holes based on the control box template.
- Drill holes and secure the control box with appropriate hardware.
- Route the control cables to the engine, avoiding sharp bends and pinch points.

2. Connecting the Control Cables

Preparation:

- Identify the throttle and shift cables.
- Measure and cut cables if necessary, following manufacturer guidelines.

Connection Procedure:

- Attach the cables to the control box, following the color-coded or labeled ports.
- Secure all connections with clamps or cable ties.
- Connect the other ends of the cables to the engine?s throttle and shift linkages.
- Adjust cable tension according to manufacturer specifications, often using a tension gauge for precision.

Important Tips:

- Ensure smooth operation without binding.
- Test the full range of throttle and shift before final securing.

3. Wiring the Electrical System

Steps:

- Connect the control box wiring harness to the boat?s electrical system.
- Use waterproof connectors or sealant to prevent corrosion.
- Verify polarity and connection points.
- Install any necessary switches or safety lanyards as per the control system instructions.
- Reconnect the battery and test electrical functions.

4. Final Checks and Testing

- Turn on the engine and test throttle response from the control box.
- Shift through all gears, ensuring smooth engagement.
- Check for any cable binding or resistance.
- Adjust cable tension if needed.
- Confirm that throttle and shift movements correspond accurately to control inputs.

Additional Tips for a Successful Installation

- Follow the Manufacturer?s Manual: Every Mercury remote throttle kit may have specific instructions; adherence ensures safety and functionality.
- Use Proper Cable Lengths: Too long cables can cause sluggish response, while too short cables may bind.
- Secure All Components: Use clamps, brackets, and fasteners to prevent movement or vibration damage.
- Seal All Connectors: To prevent water intrusion and corrosion.
- Test Thoroughly: Before heading out on the water, conduct comprehensive testing in a safe environment.

Common Challenges and Troubleshooting

Issue: Throttle or shift binding or sticking

- Solution: Check cable tension and routing; ensure no sharp bends.

Issue: Inconsistent throttle response

- Solution: Adjust cable tension; verify proper installation per instructions.

Issue: Electrical issues or no response

- Solution: Inspect wiring connections; verify fuse status and battery health.

Issue: Difficulty in shifting gears

- Solution: Ensure linkage adjustments are correct; lubricate moving parts if needed.

Maintenance and Longevity of Your Remote Throttle System

To keep your Mercury remote throttle functioning optimally:

- Regularly inspect cables for wear or corrosion.
- Lubricate moving parts according to manufacturer recommendations.
- Keep electrical connections clean and dry.
- Replace worn or damaged cables promptly.
- Periodically test the system?s responsiveness.

Conclusion: Elevate Your Boating Experience

Installing a Mercury outboard remote throttle is a rewarding upgrade that enhances control, safety, and convenience on the water. While the process requires careful planning and attention to detail, following expert guidance ensures a successful installation that provides years of reliable performance. Whether upgrading your current system or installing a remote throttle for the first time, understanding each component and step empowers you to achieve a professional-level setup, ultimately elevating your boating adventures.

Remember, if you?re ever unsure, consult with a certified marine technician or Mercury authorized

service provider to ensure optimal results. Happy boating!

QuestionAnswer What are the essential tools required for installing a mercury outboard remote throttle? You'll need screwdrivers, wrenches, wire strippers, a drill, mounting hardware, and the specific remote throttle kit provided by Mercury to ensure proper installation. How do I connect the remote throttle to my Mercury outboard motor? Connect the throttle cable to the designated control box, ensuring all wiring is properly routed and secured. Follow the wiring diagram included with your kit to match the correct terminals and test the throttle movement before final mounting. Are there any common issues to watch out for during remote throttle installation? Yes, common issues include incorrect wiring connections, cable routing interference, or improper mounting of the control box. Double-check all connections and ensure the cables move freely without kinks or obstructions. Can I install a Mercury remote throttle system myself, or should I hire a professional? While experienced boat owners can install the system themselves by following the manufacturer's instructions, it is recommended to hire a professional if you're unfamiliar with electrical wiring or mechanical mounting to ensure safety and proper operation. How do I calibrate the remote throttle after installation? Follow the calibration procedure outlined in the Mercury remote throttle manual, which typically involves setting the neutral, full throttle, and idle positions using the control box and ensuring the motor responds accurately to each input.

Related keywords: mercury outboard remote throttle, outboard control installation, remote throttle cable, mercury outboard controls, remote throttle assembly, outboard control setup, throttle link installation, mercury remote control cable, outboard engine throttle, remote control mounting

INSTALLATION MANUAL ASTEC

Installation Manual Astec

Installation Manual Astec: Your Guide to a Smooth and E?cient Setup

installation manual astec is an essential resource for anyone looking to install Astec

equipment or systems properly. Whether you are dealing with Astec power supplies,

industrial components, or electronic systems, having a clear and comprehensive manual

at your disposal can make all the di?erence between a smooth installation process and

frustrating setbacks. In this article, we?ll dive into the key aspects of using an installation manual Astec e?ectively, explore important tips, and highlight common challenges you might face along the way.

Understanding the Importance of the Installation Manual Astec

When working with specialized equipment like Astec products, the installation manual is not just a set of instructions?it?s a roadmap that ensures safety, functionality, and longevity of the device. Many users underestimate the value of closely following the manual, which can lead to improper setups, equipment damage, or even safety hazards. The installation manual Astec typically includes detailed diagrams, wiring instructions, mounting guidelines, and troubleshooting tips. These are tailored speci?cally to the product model, which is why using the correct manual is crucial. Misinterpretation or skipping steps can result in poor performance or void warranties.

What to Expect Inside the Installation Manual Astec

A typical installation manual Astec covers several core areas:

Pre-installation Requirements: This section outlines the necessary tools,

1.

environmental conditions, and safety precautions you should consider before beginning the installation.

Mechanical Installation: Step-by-step guidance on how to physically mount or

2.

position the equipment, including mounting hardware details and space

requirements.

Electrical Connections: Detailed wiring diagrams, voltage speci?cations, and

3.

grounding instructions to ensure the system operates safely and e?ciently.

Con?guration and Testing: Instructions on how to con?gure settings, perform

4.

initial tests, and verify the system is working as intended.

Maintenance and Troubleshooting: Tips to maintain the equipment in optimal

5.

condition and quick ?xes for common issues during or after installation.

Preparing for a Successful Installation

Before you even open the installation manual Astec, good preparation helps streamline

the process. Here are some practical steps to take:

Read Through the Entire Manual First

It might be tempting to jump straight into installation, but a careful read-through of the

manual will give you a full understanding of what?s required. This helps prevent surprises

and allows you to gather all necessary parts and tools ahead of time.

Gather All Tools and Materials

The manual will list speci?c tools such as screwdrivers, wire strippers, or multimeters.

Having these on hand avoids unnecessary interruptions. Additionally, check the supplied

components against the parts list to ensure nothing is missing.

Check the Installation Environment

Astec equipment often needs speci?c environmental conditions, such as temperature ranges, ventilation, or humidity control. Con?rm the installation site meets these criteria to avoid premature failure or safety issues.

Step-by-Step Guide to Installing Astec Equipment

While each Astec product might have its own nuances, the following general steps re?ect common practices outlined in most installation manual Astec documents.

1. Positioning and Mounting

Securely mounting the equipment is fundamental. Follow the manual?s guidance on orientation and clearance from other devices or walls. Use appropriate anchors or brackets as speci?ed to ensure stability.

2. Electrical Connection

This is arguably the most critical step. Always adhere strictly to the wiring diagrams in the installation manual Astec. Double-check voltage ratings, polarity, and grounding requirements. Use proper cable types and connectors to maintain safety and performance.

3. Initial Power-Up and Con?guration

Once physically installed and wired, power up the equipment according to instructions. Some Astec devices require con?guration via switches, software, or control panels. Follow the manual carefully to avoid miscon?guration.

4. Testing and Veri?cation

Run the recommended tests to verify the system?s functionality. This might include checking voltages, output signals, or operational parameters. Document your results to keep track of the installation quality.

Common Challenges and How to Overcome Them

Even with a detailed installation manual Astec, users can face hurdles. Here are some typical challenges and tips to handle them:

Ambiguous Instructions or Technical Jargon

Some manuals can be dense or use industry-speci?c language. If you encounter confusion, look for supplementary resources such as video tutorials, online forums, or Astec customer support.

Missing or Damaged Parts

Before starting, verify all components are intact. If anything is missing or faulty, contact the supplier immediately rather than improvising, which may compromise safety.

Electrical Wiring Issues

Incorrect wiring is a frequent cause of installation failures. Use a multimeter to con?rm connections and ensure power is o? when handling cables. If unsure, consult a professional electrician.

Tips for Maintaining Astec Equipment Post-Installation

An installation manual Astec often includes maintenance recommendations to prolong

equipment life. Here are a few general tips:

Regularly inspect connections and mounting hardware for signs of wear or

1.

loosening.

Keep equipment clean and dust-free, especially cooling vents or fans.

2.

Follow scheduled maintenance checks outlined in the manual to detect early faults.

3.

Use only recommended replacement parts and accessories to maintain warranty

4.

compliance.

Why Following the Installation Manual Astec Matters for Safety

Safety should never be an afterthought. Astec products often operate with high voltages or sensitive electronics. The installation manual Astec provides critical safety warnings and procedures designed to protect both the installer and end-users. Ignoring these can lead to electrical shocks, ?re hazards, or permanent damage to the equipment.

By respecting these guidelines, you not only safeguard yourself but also ensure that the equipment performs reliably over time, avoiding costly downtime or repairs.

Installation manual Astec is more than just a technical document?it?s your key to unlocking the full potential of your Astec equipment. Taking time to understand and follow it carefully pays o? in e?ciency, safety, and performance. Whether you?re a seasoned

technician or a ?rst-time installer, approaching the manual with respect and attention will help you achieve the best results with con?dence.

Question

Answer

What is the purpose of the Astec installation manual?

The Astec installation manual provides step-by-step instructions and guidelines to correctly install Astec products, ensuring safety, e?ciency, and optimal performance.

Where can I ?nd the latest Astec installation manual?

The latest Astec installation manual can typically be found on the o?cial Astec website under the support or resources section, or by contacting Astec customer service directly.

Does the Astec installation manual include safety precautions?

Yes, the Astec installation manual includes detailed

safety precautions to prevent accidents and damage

during the installation process.

Are there speci?c tools

required as per the Astec

installation manual?

Yes, the manual lists all necessary tools and

equipment required for proper installation of Astec

products to ensure the process is completed e?ciently

and correctly.

Can the Astec installation

manual be used for all Astec

product models?

The manual is usually speci?c to particular product

models or product lines, so it's important to use the

installation manual that corresponds to your speci?c

Astec product model.

Does the Astec installation

manual cover both indoor and

outdoor installations?

Depending on the product, the Astec installation

manual may cover instructions for both indoor and

outdoor installations, including environmental considerations and mounting requirements.

Is technical support available if I encounter issues during installation according to the Astec manual?

Yes, Astec typically o?ers technical support via phone, email, or online chat to assist customers with any installation issues encountered while following the manual.

Are there any warranty conditions linked to following the Astec installation manual?

Yes, following the instructions in the Astec installation manual is usually required to maintain the product warranty, as improper installation can void warranty coverage.

How detailed is the Astec installation manual in explaining wiring and electrical

connections?

The Astec installation manual provides detailed

diagrams and instructions for wiring and electrical

connections to ensure safety and compliance with

electrical standards during installation.

Installation Manual Astec: A Detailed Exploration of Best Practices and User Guidance

installation manual astec serves as a critical resource for technicians, engineers, and

end-users aiming to set up Astec equipment correctly and e?ciently. Whether dealing with power supplies, industrial machinery, or specialized components, the installation manual embodies the nexus between product design and practical application. This article delves into the nuances of the Astec installation manual, highlighting its structure, pivotal features, and how it facilitates seamless deployment in various operational contexts.

Understanding the Purpose and Scope of the Installation Manual

Astec

The installation manual provided by Astec is more than just a procedural document; it is a comprehensive guide designed to ensure safety, optimize performance, and prolong the lifespan of the equipment. Astec, known for its robust power conversion and industrial solutions, incorporates detailed instructions that cover everything from unpacking the device to ?nal calibration.

A well-crafted installation manual astec typically addresses:

Pre-installation safety checks and environmental requirements

1.

Step-by-step assembly and mounting procedures

2.

Electrical wiring and connection diagrams

3.

Initial startup and con?guration protocols

4.

Troubleshooting tips and maintenance recommendations

5.

This structured approach helps mitigate risks associated with incorrect installations, such as equipment damage or operational hazards, which are particularly critical in industrial settings where Astec products are commonly deployed.

Key Components of an Astec Installation Manual

Astec?s installation manuals stand out for their clarity and technical depth. Key components often include:

Safety Guidelines: Detailed warnings and precautionary measures tailored to the

1.

speci?c equipment.

Tools and Materials Required: A checklist to prepare users prior to installation.

2.

Physical Installation Instructions: Detailed steps for mounting and securing

3.

devices, often supported by diagrams.

Electrical Installation: Comprehensive wiring schematics and grounding

4.

requirements.

Con?guration and Testing: Procedures for initial operation and veri?cation of

5.

proper function.

The inclusion of diagrams and technical illustrations is particularly important, as they provide visual clarity that complements textual instructions. This dual-mode communication is essential for both novice installers and experienced technicians.

Comparative Analysis: Astec Installation Manual vs. Industry Standards

Comparing the Astec installation manual to other industry manuals reveals several noteworthy distinctions. While many manufacturers provide basic installation instructions, Astec?s manuals frequently integrate enhanced diagnostic advice and maintenance considerations. For example, some competing manuals may omit detailed startup calibration procedures, which are crucial for ensuring system e?ciency and longevity. Moreover, Astec emphasizes compliance with international safety standards such as IEC

and UL certi?cations. The manuals re?ect these compliance aspects through standardized labeling, symbols, and terminology, facilitating easier understanding across global markets.

Advantages of Following the Astec Installation Manual Precisely

Adhering strictly to the installation manual astec o?ers several bene?ts:

Enhanced Equipment Longevity: Correct installation reduces wear and potential

1.

breakdowns.

Safety Assurance: Proper grounding and wiring minimize electrical hazards.

2.

Operational E?ciency: Optimal setup leads to better performance and energy

3.

savings.

Warranty Protection: Many manufacturers require documented adherence to

4.

installation protocols for warranty validity.

These advantages underscore the manual?s role not just as a guideline but as a safeguard for both the equipment and the user.

Challenges and Considerations During Installation

Despite the thoroughness of the Astec installation manual, users may encounter

challenges related to environmental conditions, technical complexity, or equipment variations. For instance, installations in harsh or variable climates may require supplementary precautions not explicitly outlined in the manual.

Furthermore, complex electrical connections necessitate a certain level of expertise. While the manual is designed to be user-friendly, installers unfamiliar with industry-standard wiring conventions might need additional training or professional assistance.

Recommendations for Optimal Use of the Installation Manual Astec

To maximize the bene?ts of the installation manual, consider the following best practices:

1. Read the entire manual before beginning any physical installation work to understand the full scope.

2. Prepare all tools and materials in advance, ensuring compatibility with the speci?cations listed.

3. Follow safety instructions meticulously, especially when dealing with high-voltage components.

4. Use the diagrams and wiring schematics as primary references during setup.

Document each step of the installation process, noting any deviations or issues

5.

encountered.

Consult Astec?s technical support resources if uncertainties arise.

6.

Implementing these guidelines can reduce installation time and prevent costly errors.

Digital Accessibility and Updates in Astec Installation Manuals

In the digital age, accessibility and up-to-date information are crucial. Astec has adapted by o?ering installation manuals in electronic formats such as PDFs, accessible via their o?cial website or customer portals. This facilitates quick retrieval and ensures that users have access to the latest revisions re?ecting product updates or regulatory changes. Additionally, interactive manuals with embedded videos or troubleshooting modules are emerging trends that Astec and similar manufacturers are beginning to explore. These enhancements can further simplify complex procedures and improve user con?dence during installation.

The Role of Installation Manuals in Post-Installation Support

Beyond the initial setup, the installation manual astec acts as a reference document for ongoing maintenance and troubleshooting. Users can consult the manual to identify the root causes of operational issues and perform routine checks recommended by the manufacturer. This proactive approach to equipment care can prevent downtime and extend service intervals.

Moreover, the manual?s detailed speci?cations assist service professionals in diagnosing

problems accurately and e?ciently, reducing repair times and costs.

As industries increasingly rely on sophisticated equipment, the value of a well-developed installation manual becomes even more pronounced. Astec?s commitment to comprehensive documentation re?ects its dedication to customer satisfaction and operational excellence.

installation guide astec, astec setup instructions, astec product manual, astec user guide, astec equipment installation, astec system setup, astec technical manual, astec assembly instructions, astec operation manual, astec installation procedures

Read the full article online: INSTALLATION MANUAL ASTEC